

Chemical Fingerprinting Program for RSRM Critical Materials

Presented by:

William H. McClennen

Dennis J. Fife



Michael O. Killpack

Rick P. Golde

September 16-18, 2002




THIOKOL PROPULSION




010530ppt

Presentation Outline



- **Background**
- **Objectives and Approach**
- **Accomplishments**
 - **Description of Database Viewer**
 - **Success Stories**
 - **Direct and Additional Benefits**
- **Continuing Challenges**
- **Acknowledgements**

Reusable Solid Rocket Motor (RSRM) Components Involving Critical Materials




- Segmented steel case
- Movable nozzle
- Case-bonded, composite solid propellant
- Elastomeric internal insulation
- Nozzle ablative liner
- Nozzle insulator and structural shell
- Clean bonding surfaces
- Effective adhesives

Background: Chemical Fingerprint Definition

Diagnostic Combination of Analytical Methods for Detailed Characterization of a Material

- Key importance is a chemical fingerprint that can be used to identify a material, to differentiate it from similar looking materials, or lead to its source
- In the past, fingerprinting methods were used to characterize materials and processes
 - Following a failure or noncompliance
 - Ad hoc, reactive, and incomplete generation and storage of data
 - Database scattered over dozens of file cabinets
 - Few techniques were adopted for receiving inspection/process control






Objectives of Chemical Fingerprinting (Recognize, Reduce, Resolve Problems)

- Detailed understanding of material composition
- Enhanced ability to detect changes in a material due to vendor changes or subtler supplier changes
 - Improved acceptance testing based on chemical composition
- Improved understanding of how a material works, ages, degrades, etc.
- Standardized approach to material fingerprinting
- Develop methods for monitoring all key ingredients
- Develop a comprehensive material database
- Reduced probability of unexpected and unrecognized changes to critical materials and processes

Approach: State of Art Facilities

- **Chemical Characterization**
 - **NMR (300 and 400 MHz)**
 - **Surface analysis**
 - ESCA/XPS
 - Auger
 - SIMS
 - ISS
 - **RAMAN / FTIR / NIR**
 - **Metals analysis**
 - ICP emission
 - AA/GFAA
 - ICP-MS
 - **X-Ray Fluorescence**
 - **Chromatography**
 - HPLC/HPLC-MS
 - GPC
 - GC (various detectors)
 - GC-MS
 - Ion chromatography
 - **Flow injection auto analyzer**
 - **CHN O/S**
 - **Classical techniques**
 - **Asbestos identification**
- **Thermal Analysis**
- **Mechanical Properties**
- **Non Destructive Analysis**




Approach: Material Team

Team Members

Material Specialist
M&P Specialist
Design Engineer
Procurement Quality Engineer
Manufacturing Engineer
Process Control Lab


R&D Analytical Laboratories
R&D Materials and Process
S&E Engineering
Quality
Operations
Quality Lab (material receipt)

Material Fingerprinting Approach




Data Management

Fingerprinting Data Manipulation and Storage



Database Components and Software (No Commercially Available Integrated System: Integration and Data Parsing Developed Internally)

- Server-based PC Network: Novell®
- Data loader and Viewer: developed software programs internally using PowerBuilder®
- Oracle® database
- LIMS (Lab Information Management System) software: Nautilus® R2B2, LabSystems
- Spectroscopic/
Chromatographic Data Viewer:
Grams/32® v. 7.0, LabSystems,
Galactic Industries



Ion Chromatography Analysis

Accomplishments: RSRM Fingerprinting Materials

- **55 Materials completed or in process**
 - **11 Solvents or cleaning solutions**
 - **Phenolic resin and 3 phenolic composites**
 - **4 Compounded rubber insulations**
 - **2 Propellant systems**
 - **10 Polymeric components**
 - **3 Sealants and ablative compounds**
 - **5 Rubber adhesives**
 - **3 Epoxy based adhesives**
 - **5 Paints and primers**
 - **7 Inorganic fillers, abrasives and reactive components**
 - **1 Corrosion inhibiting grease**

Accomplishments: Database Viewer Features

- Executive view
 - Material overview, reference documents, data examples
- Method information
 - Chemical characterization methods
- Component information
 - Trend analysis and visualization of key analytes
- Method quality control
 - Trend analysis of QC parameters
- View comparison
 - Direct graphical overlay of raw spectroscopic and chromatographic data
- Lab notes

Material Fingerprinting Success Example

- Neoprene FB
 - Secondary polymer used as a component in case insulation EPDM formulations
 - Material no longer produced
 - Fingerprinting showed that under proper storage conditions: Neoprene FB could be stored over 10 years and still meet specification
 - Storage at 40°F, low humidity, and minimal light
 - Stockpiled 100,000 lb till new EPDM formulation can be qualified
 - Test methods developed to ensure material is well within specification
 - Viscosity measurement performed as a check at the vendor's storage site, while the GPC and FTIR analyses confirm the molecular weight distribution and the chemical composition
 - Defense program experienced solvating problem with gum stock for carbon fiber EPDM
 - Fingerprinting knowledge allowed immediate identification of the problem
 - Corrective action given on controlling Neoprene FB

Presentation Module: Executive Screen for Neoprene FB

Material Name

Neoprene FB

Stock #

Usage

Personnel

Stock Numbers

Report

Executive View

Method Information

Component Info

Method QC

View Comparisons

Lab Notebook

Material

Neoprene FB is a secondary polymer used as a component in two silica filled EPDM insulation formulations and in Carbon Fiber Filled EPDM. Neoprene FB is a low molecular weight polychloroprene (poly(2-chloro-1,3-butadiene)) used in these EPDM formulations to control plasticity and to enhance bonding characteristics. There are also some flame retardant capabilities associated with the Neoprene FB. The three RSRM EPDM formulations that use Neoprene FB are as follows:
Silica filled EPDM
Lab No. 053A-Systems tunnel floorplate shear ply, LSC









Description

Compounds (double click for structure)

2-CHLORO-1,3-BUTADIENE-SULFUR COPOLYMER	93	% g/g
CHLORONAPHTHALENES	4.2	% g/g
SULFUR	1.2	% g/g
TETRAETHYLTHIURAM DISULFIDE	0.6	% g/g
DIMETHYLDIETHYLTHIURAM DISULFIDE	0.5	% g/g
TETRAMETHYLTHIURAM DISULFIDE	0.05	% g/g

Value Units

Reference Data

Reference Information

mmv_vs_line_chart.xls

Neoprene_aging.xls

Neoprene_aging_Studies_Dupont.xls


neoprene_brookfield_50C.xls

Neoprene_FB_presentation.doc

Close

Material Example: Neoprene FB in EPDM

EPDM Usage in Booster Motor



Method Information Screen


THIOL PROPULSION

Description	Method Ref.	Test	Dept. Name	Dept. Abbr.
C.H. and N Elemental Analysis	LTP-33H1-1030-FP1800	CHN_F1800	Auto Analyzer	AU
DSC Analysis - Low Temperature Scan	LTP-33H1-1176-FP1500	DSC_F1500	Differential Scanning Calorim	DSC
Neoprene FB - GPC Analysis	LTP-33H2-1099-FP0300	GPC_F0300	Gel Permeation Chromatography	GPC
FTIR Analysis	LTP-33H2-1069-FP0700	FTIR_F0700	Infrared Spectroscopy	IR
FTIR Analysis - Quality Compare	LTP-33H2-1069-FP0700	FTIR_F0700_QC	Infrared Spectroscopy	IR
Neoprene - Analysis by HPLC	LTP-33H2-1136-FP0100	LC_F0100	Liquid Chromatography	LC
Neoprene - Brookfield Viscosity	LTP-33H1-1101-FP2100	ME_F2100	Mechanical Testing	ME
Neoprene - RDS	LTP-33H3-1100-FP2000	RDS_F2000	Mechanical Testing	ME
Neoprene - ICP AES Analysis	LTP-33H1-1102-FP1001	ICP_F1001	Metals Analysis	MT
NMR Analysis (Carbon-13)	LTP-33H1-1079-FP0800	NMR_F0800_C13	Nuclear Magnetic Resonance	NMR
NMR Analysis (Proton)	LTP-33H1-1079-FP0800	NMR_F0800_H	Nuclear Magnetic Resonance	NMR
Thermal Gravimetric Analysis	LTP-33H1-1156-FP1600	TG_F1600	Thermogravimetric Analysis	TG


Highlighted items are primary tests

Material Account # 0378


Component Info: Analyte Trends




Method QC: Duplicate GPC Analysis Trends



View Comparison: FTIR Data



Analysis Details: FTIR Spectra From Aging Study



Material Fingerprinting Successes/Improvements (cont'd)

- **HC polymer, carboxy terminated polybutadiene (CTPB)**
 - **This liquid polymer is used in the liner that bonds the propellant to the case insulation.**
 - **Understanding the details of the polymer and the manufacturing process enabled analysts to identify a noxious byproduct at increased levels that was making operators sick.**
 - The bad lot was taken out of production and a corrective action was developed to improve the vendor's manufacturing process.
 - A detection and quantification method with new limits for the byproduct is in place for acceptance of future lots.
- **In-depth fingerprinting knowledge has also been invaluable for the development of the replacement after current vendor announced the closure of their HC polymer plant.**
 - Initial carboxy terminated polybutadiene (CTPB) received from a new vendor showed distinct differences from HC polymer in small acids and molecular weights.
 - Recommendations to improve reaction mixture ratios as well as process washing and drying have enabled new vendor to produce acceptable polymer, now being tested for use on RSRM.
 - Also developing acceptance testing and spec limits for both commercial and defense programs with this new material.

Material Fingerprinting Successes/Improvements (cont'd)

- **BRULIN 1990 GD-T**
 - ODC replacement for methyl chloroform vapor degreasing
 - Water-based solvent used with spray-in-air technology
 - Several issues developed with material during certification
 - Material received with insoluble material in drums
 - Material received with lower than expected pH
 - Vendor asked for site visit from Thiokol's chemist
 - Knowledge from fingerprinting provided information to stabilize product through small changes in use of de-ionized water, mixing steps, and cycles
 - Use of hydrated silicates
 - Recommendation for KOH add back to spray-in-air baths
 - Increased useable bath life from 8 to 90 days
 - Knowledge from fingerprinting effort provided suggestion for corrosion inhibitor rinse cycle (new inhibitor currently qualified)

Material Fingerprinting Successes/Improvements (cont'd)

- MAPO (Methyl Aziridiny Phosphine Oxide)
 - Used as a curative for the liner between insulation and propellant
 - Recent Lot received with incomplete certification
 - Acceptance testing indicated material was out of specification for reactive imine, hydrolyzable chloride and total chloride
 - Additional tests were done per the fingerprinting SLP that supported the previous testing and included GPC data that began to suggest the nature of the problem
 - Further testing using more detailed techniques (HPLC/MS) developed through fingerprinting in R&D Labs identified the process by-product impurities and aided vendor in finding a resolution
 - Material returned to vendor for reprocessing

Material Fingerprinting Successes/Improvements (cont'd)

- **TCA – Methyl Chloroform**
 - **Ozone Depleting Chemical (ODC) TCA has limited availability due to restrictions for defined essential use.**
 - **A large amount of stored TCA had exceeded its shelf life and deteriorated out of specification.**
 - **Distillation was proposed as a recovery technique, but there was uncertainty on its effects on the stabilization components.**
 - **Fingerprinting analyses were able to prove the distilled material acceptable to NASA.**
 - **Basic understanding has also identified problems with long-term storage of the TCA from a second source due to incompatibility between two components in its stabilizer package.**
 - **Currently working with vendor, design and manufacturing engineers to assess new methods for storage to ensure this critical solvent will be available until a replacement solvent can be qualified or, if necessary, for the life of the RSRM program.**

Material Fingerprinting Successes/Improvements (cont'd)

- Corrosion inhibiting grease from new plant verified with FTIR
 - Vendor tried a new formulation but reverted to original catalyst after fingerprinting confirmed it gave most consistent result
- D-limonene containing solvents removed from use on uncured rubber after testing confirms degradation of cure system
- BHT identified as a minor additive to inhibit d-limonene degradation in solvents
- Detailed fingerprinting of rubber to metal adhesives has provided new insight into aging processes plus new ways to monitor aging
 - Aging studies indicate resin interaction as early step in degradation
 - Significant reduction in shelf life with certain environments
 - New methods provide early warning of potential problems

Direct Benefits of Fingerprinting

- Fundamental understanding of critical materials that often equals or exceeds vendor's knowledge
 - Provide baseline chemical profile of materials in use
 - Material changes can often be traced to their source
- Standardized approach including:
 - Material team for focus and relevance
 - Flexible test plan for method adaptation or development
 - Laboratory team for technical expertise
 - Final report and R&D procedures to document method development
 - SLP of key down-selected robust methods in standard format for routine use in Process Control Lab
- Material team technical ownership
 - Analytical chemist as material specialist
 - Improved communication between procurement, work centers, quality and labs

Additional Benefits of Fingerprinting

- **Versatile database broadly available both for new lot comparison and problem solving**
 - Available plant-wide and informative on many levels of detail
 - Trending of key parameters and QC data as well as detailed overlay
 - Lot-to-lot consistency monitored and changes flagged
 - Security functions provide protection for vendor proprietary information
- **Improved vendor relationships through data and method sharing**
 - New methods shared with vendors to enhance their capabilities
 - Vendors acknowledge our expertise and expand cooperation by timely reporting of planned changes
- **Greater efficiency and confidence in requalification/qualification of materials due to obsolescence or changes in vendor or production site**

Continuing Challenges

- Down selection for Process Control Lab
 - Basic chemical characterization
 - Methods robust and simple enough for routine analysis
 - Key component information – what is likely to go wrong next
 - History of materials and vendors
 - Dependable crystal ball
- Implementation in Process Control Lab
 - Training at higher level of technical expertise
 - Greater demands on LIMS and data entry
 - Setting limits for new acceptance criteria
- Data utilization
 - Continuing education of vendors and engineers

Acknowledgements

- Vision of NASA/MSFC and Thiokol management to see the benefits of a formal Fingerprinting Program
- NASA funding through Marshall Space Flight Center
- Data sharing cooperation of material vendors
- Analytical efforts of Thiokol material specialists, scientists, and engineers

